

STRIPPING SCREENS

ART 125 SILKSCREEN

1. Put on gloves, protective clothing, goggles and ear protectors
2. Spray your screen on both sides with hot water.
3. Spray screen with stripper solution
4. Let solution soak into emulsion for 1-2 minutes (the emulsion should become runny)
5. *** Rinse the stripper solution from your screen and rinse down the drain with the garden hose.
6. Turn on cold water supply for power washer (on back sink). Make certain water is cold.
7. Turn on power washer (rocker switch is on the top)
8. Set the spray nozzle on power washer wand for a medium spray (it should spray around 12" wide).
9. Begin removing the emulsion from your screen
10. Inspect screen to make certain all emulsion is removed. If emulsion remains continue to power wash the screen before it dries.
11. Turn off cold water supply to power washer.
12. Return goggles, ear protectors and other equipment to their proper location.